



NOTE: Pins from emulation socket go straight through, For example, Pin 1 from the emulation socket goes to pin 1 on the DIL socket. This is the same all the way up to pin 28.

**Bottom six pins
NOT connected**